



- NOTES:**
1. APPLY MAGNALUBE LUBRICANT TO THE KNURLED CUP POINT OF SET SCREW (816846) BEFORE ASSEMBLING.
 2. CASE (812580) & NOSE (812133) MUST WITHSTAND A MINIMUM OF 60 IN'LBS OF TORQUE IN THE COUNTER-CLOCKWISE DIRECTION BEFORE COMING APART.
 3. APPLY MAGNALUBE LUBRICANT TO THE GUIDE BALLS (816886), SLOTS OF SHAFT (812140) & DIMPLED INSERT (816852).
 4. LIGHTLY LUBRICATE INSIDE OF SPRING (812525) WITH MAGNALUBE.

LEGEND: () = Quantity/Tool

* = Quantity/Multi-Pak

INSTRUCTIONS

857182
HEX KEY
812151



DIVISION OF RYSON CORPORATION

THIS PRINT AND ALL INFORMATION APPEARING THEREON IS THE PROPERTY OF STURTEVANT/RICHMOND. NEITHER THE PRINT NOR THE INFORMATION THEREON MAY BE REPRODUCED OR USED IN ANY MANNER WHATSOEVER, DIVULGED TO ANY OTHER PERSON UNLESS SPECIFICALLY AUTHORIZED BY STURTEVANT/RICHMOND.

PART DESCRIPTION

PM-15

DIAGRAM NO. & REV.
810064-S